



## **Boltless Industrial Storage Rack**



- Start by assembling an end frame. Take two (2) uprights (RLSU), with one (1) brace (RMB). Skipping one (1) slot from the bottom of each upright (see figure A), place the rivets into the slots of the upright with the flat part facing up and tap lightly to properly seat rivets (See figure B). Continue by adding the remaining braces to complete the necessary levels for the end frame.
- Continue by constructing another end frame. Be sure to place the braces in the same upright slot locations as the first end unit so that both end units are identical.
- 3. Next install the beams (RLB). Skipping one slot from the bottom of each upright, place the beam rivets into the slots of the upright with the flat part facing up and tap down lightly to properly seat the rivets. Start at the bottom of the end unit and work your way to the top aligning the beam rivets with the rivets of the front to back braces. DOUBLE CHECK the unit and BE SURE that all rivets are properly seated.
- 4. Next install the center supports (CS) to the center rivets of the beams. Start by locating the rivets facing inward on the beams, then with the flat side facing up place the shelf center support hole slot to the top rivet and the notch to the bottom rivet (see figure D). Do this on both ends of the shelf center support, then tap lightly to property seat.

If you purchased an add-on unit there are a few steps that need to be followed. First make sure that the base unit is free of all items stored. Start by removing two (2) uprights (RLSU) at one (1) end of unit, and the braces (RFB) that are connected to it (see figure D). Take two (2) of the add-on uprights (RLPT), and install them in place of where the uprights (RLSU) were removed. Continue by adding the necessary braces (RFB) to both sides of the add-on uprights to re-complete the base unit (see figure E). Using the uprights removed from the base unit (RLSU), continue by adding beams and braces following step one (1) from this instructions sheet (See figure F)



H-1081-FRAME R H-1203-FRAME R H-1389-FRAME R H-1531-FRAME R														H-1600-TRAME		H-1204-BEAM R	H-1082-BEAM R				H-1001-BEAM					H-1525-BEAM					H-2188-REAM	RLPT8-2	RLPT6-2	RLPT5-2	H-1894-POST			H-2188-POST	Customer	Item Number	
DI DIVOZIA	RLBK9824-1	RLBK9618-1	RLBK7248-1	RLBK7236-1	RLBK7224-1	RLBK7218-1	RI BK6048-1	RLBK6036-1	RLBK6024-1	RLBK6018-4	DI BKARASA	RI BKARSE	DI BKARSA-1	REDROGA-1	RLBK3818-1	RLBK9648-3	RLBK9636-3	RLBK9624-3	LBK9618-3	RLBK7248-3	LBK7234-3	LBK7218-3	LBK6048-3	RLBK6036-3	LBK6024-3	RLBK8018-3	RLBK4836-3	RLBK4824-3	RLBK4818-3	RLBK3624-3	RI BKIRIS-1	RLPT8-2	RLPT6-2	RLPT6-2	RLPK96-4	RLPK84-4	RLPK72-4	RLPK60-4	EI Casa		Rivet Lock Kits
90 2 00	34	96 x 18	72 x 48	72 x 36	72×24	72 x 18	80 x 48	60 x 36	80 x 24	80 x 18	48 × 48	20 x 20 x	48 4 24	48 × 18	36 x 18	96 x 48	96 x 36	98 x 24	90 x 16	72×48	75 × 24	72 × 18	60 x 46	60 x 36	60 x 24	80 x 18	48 x 36	48 x 24	20.12	36 x 24	38 × 18	96	72	80	96	84	72	8	Size		Kits
DAME & LIANCE	-	add-on 1 level	add-on 1 level	-	-4	mak la	4	ale .	4		4. 4	arkd-on 1 level	di a	add on I lavel	-	starter 3 levels	starter 3 levels	20	w	starter 3 levels	Sievel C Jenets	w	starter 3 levels	CO :	0	starter 3 levels	0 60	starter 3 levels	4	60.0	starter il levels		13	tee-post kit 2 posts	post krit 4 positili	post kil 4 posts	post kit 4 posts	post kit 4 posts	Levels	Description	
	2 12	N	N.	2	2	N	2	21	01	0 1	J P	3 N	د ی	OK	10	Ġ,	m	co	m	ch c	0	රා	o	0	00 (	<b>D</b>	p (3)	6	0	G9 4	0			ı					RLB	Beam	
	, N	2	2	N	2	21	21	2	2	0,0	40	21	٥	3 10	N	a	0	0	6	do d	n a	ග	a	œ (	de d	30 0	0 00	o	0	0	0			ı				İ	RFB	Brace	Ω
0	نئ د	Ç.	2	2	2	2.	4			4			-		-	0	89	9	9	0	0	0	ç	ço i	<b>W</b>	w 0	ه ده	w	ω (	ia: c	٥								0	Center	omponent Pieces
																l															ı				۵	4	4	4	RLU	Post	95
																ı				1				1					I		ı	2	2	2					RLPT	Post	